



[www.ototest.net](http://www.ototest.net)

**GÜNCEL TÜRKÇE OBD II ARIZA KODLARI  
TEKNİK BİLGİLER  
ARIZA TESPİT CİHAZLARI**

TOYOTA

- P1100 BARO Sensor Circuit.
- P1120 Accelerator Pedal Position Sensor Circuit.
- P1121 Accelerator Pedal Position Sensor Range/Performance Problem.
- P1125 Throttle Control Motor Circuit.
- P1126 Magnetic Clutch Circuit.
- P1127 ETCS Actuator Power Source Circuit.
- P1128 Throttle Control Motor Lock.
- P1129 Electric Throttle Control System.
- P1130 Air/Fuel Sensor Circuit Range/Performance. (Bank 1 Sensor 1)
- P1133 Air/Fuel Sensor Circuit Response. (Bank 1 Sensor 1)
- P1135 Air/Fuel Sensor Heater Circuit Response. (Bank 1 Sensor 1)
- P1150 Air/Fuel Sensor Circuit Range/Performance. (Bank 1 Sensor 2)
- P1153 Air/Fuel Sensor Circuit Response. (Bank 1 Sensor 2)
- P1155 Air/Fuel Sensor Heater Circuit. (Bank 1 Sensor 2)
- P1200 Fuel Pump Relay Circuit.
- P1300 Igniter Circuit Malfunction - No. 1.
- P1310 Igniter Circuit Malfunction - No. 2.
- P1335 No Crankshaft Position Sensor Signal - Engine Running.
- P1349 VVT System.
- P1400 Sub-Throttle Position Sensor.
- P1401 Sub-Throttle Position Sensor Range/Performance Problem.
- P1405 Turbo Pressure Sensor Circuit.
- P1406 Turbo Pressure Sensor Range/Performance Problem.
- P1410 EGR Valve Position Sensor Circuit Malfunction.
- P1411 EGR Valve Position Sensor Circuit Range/Performance.
- P1500 Starter Signal Circuit.
- P1510 Boost Pressure Control Circuit.
- P1511 Boost Pressure Low.
- P1512 Boost Pressure High.
- P1520 Stop Lamp Switch Signal Malfunction.
- P1565 Cruise Control Main Switch Circuit.
- P1600 ECM BATT Malfunction
- P1605 Knock Control CPU.
- P1630 Traction Control System.
- P1633 ECM.
- P1652 Idle Air Control Valve Control Circuit.
- P1656 OCV Circuit.
- P1658 Wastegate Valve Control Circuit.
- P1661 EGR Circuit.
- P1662 EGR by-pass Valve Control Circuit.
- P1780 Park/Neutral Position Switch Malfunction (Only For A/T)